




(636) 937-2927
(636) 296-9292
(573) 431-5200
(800) 600-9292

Programming an Easy Reader Thermostat Heat or Cool

Program Thermostat

1. Press button (1) for **Heating Programming**
2. Press button (8) for **Cooling Programming**
3. Press **Menu** (2) button
4. Press **Sched** (3) button
5. Press **Up** or **Down** (4) or (6) button to set desired temperature.
6. Press the **Time** (5) button to set desired program time.
7. Press **Up** or **Down** (4) or (6) button to change time **(15 min. inc.)**
8. Press **Sched** (7) button to go to next program period
9. Press **Adv Day** (8) button to go to next day of the week
10. When Program is complete, press **Run** (9) button



For a 2 Hour Temporary Change, press **Up** or **Down** (4) or (6)

For temporary changes longer than 2 hours, press the **Up** or **Down** buttons (4) or (6) then press **Hold (2)**